

Thank you for purchasing this product from Gopher.



If you are not satisfied with any Gopher purchase for any reason at any time, contact us and we will replace the product, credit your account, or refund the purchase price.

Read instructions in their entirety. In the event of missing parts, call 1-800-533-0446.

Limited Technology Product Warranty

Due to the sensitivity of technology products and circumstances beyond Gopher Sport's control, Gopher Sport warrants to the original purchaser that the FITstep[™] Stream[™] and HUB[™] shall be free from defects in quality, materials, and workmanship under normal use for a period of one year from the date of purchase.

The Limited Technology Product Warranty does not cover the replacement of batteries or problems arising from improper handling.



Windows Software Manual

Operating System Requirements

	Minimum	Recommended
Operating System	Windows 10	Windows 11
Processor	Intel Core i7	Intel Core i9
Memory (RAM)	2GB	4GB
Storage Space	50 MB	100 MB

Step 1: Installing FITstep[™] Pro Software

Go to <u>www.gophersport.com/software</u> and select the '**Windows FITstep™ Pro Software Download**' button to begin downloading the latest version of FITstep™ Pro software for macOS.

IMPORTANT: Do NOT connect the Gopher FITstep[™] Reader Station to your computer prior to launching and setting up the FITstep[™] software. The reader station will be connected once the application is set up correctly.

Double click on the downloaded file to begin software installation. You will be prompted to start the installation, as well as choose a location for where you would like to install the application.

🛃 FITstep v4.2 — 🗌 🗙	💕 FITstep v4.2 — 🗆 🗙
Welcome to the FITstep v4.2 Setup Wizard	Select Installation Folder
The installer will guide you through the steps required to install FITstep v4.2 on your computer.	The installer will install FITstep v4.2 to the following folder. To install in this folder, click "Next". To install to a different folder, enter it below or click "Browse". Eolder: [C:)Frogram Files (x86)(Gopher Sport/FITstep v4.2) Browse
WARNING: This computer program is protected by copyright law and international treaties. Unauthorized duplication or distribution of this program, or any portion of it, may result in severe civil or criminal penalties, and will be prosecuted to the maximum extent possible under the law.	Disk Cost Install FITstep v4.2 for yourself, or for anyone who uses this computer: Everyone Just me
< Back Next > Cancel	<back next=""> Cancel</back>

When the installation is complete, a Gopher FITstep[™] Version 4.3 icon will be placed on your desktop for easy startup.

NOTE: All current FITstep[™] data is converted to work with the latest version of FITstep[™] software, and a backup file is created for compatibility with older versions of FITstep[™] software.



Step 2: Launch and Setup FITstep[™] Pro Software

To launch the application, double click the application icon for FITstep[™]. Upon launch, the first thing you will need to do is set up a database file to use with the FITstep[™] software.

Database Files

FITstep[™] requires a database file be placed on your computer in order to save and track pedometer data. If launching the FITstep[™] software for the first time, you will be prompted to create this database file.

Choose 'Create New Database' and select 'OK'. A new database file called 'pedometerData.db' will be created in the root of your Documents folder in Windows.

If you used previous versions of the software, your database file will convert so it works with the new software. If you use multiple databases or want to open one you converted from the old software, use the following steps:

- 1. File
- 2. Open Database
- 3. A finder window will open and allow you to search for your desired database
- 4. Select the database and click Open

Create New Database File

To create a new database file, follow these steps:

- 1. Go to the application menu bar and select 'File > New Database' and enter a unique name for the database when the following prompt is presented:
- 2. This new database file will have the name provided and the .db extension. The database file will be located in the root directory of your Documents folder. It is recommended to change this location and store database files on the computer's desktop for easy access.

NOTE: If the FITstep[™] application is being used by multiple users, each user should create a new database file for their needs.

Open Existing Database File

If this is NOT your first time using FITstep[™] software, your current database file will be converted to work with the latest version of the application.

To open a converted database file, or if multiple users have unique database files, follow these steps:

- 1. Go to the application menu bar and select 'File > Open Database' from the menu.
- 2. A Finder window will open your Documents folder in order to select the database file you would like to use.
- 3. Select the database file you would like and click 'Open'. This will load the selected database file and its data into FITstep[™].

Step 3: Gopher FITstep[™] Pro Reader Station Setup

The reader station is required to transfer data from the FITstep[™] Pro Pedometer to the FITstep[™] software application.

To set up the reader station, follow these steps:

- 1. Plug the reader station into your computer using the provided USB cable.
- 2. The reader station will be automatically recognized by your computer and registered by your computer.

NOTE: The FITstep[™] application will NOT show an activity indicator during the setup process. You will know the reader station has been set up correctly when an indicator, located under the FITstep[™] logo in the lower left-hand corner of the application, labeled 'FITstepPro Readers: 0' has been updated to now indicate, 'FITstepPro Readers: 1', where '1' indicates the number of reader stations you have connected to your computer successfully.



X FITstep v4.2		- 🗆 ×
Eile Import/Export Pre	ferences Help	GOPHER XFITstep
 Mr. Smith 	Class Setup Upload Pedometer Data Pedometer Setup Reports	
 Sth Grade 3rd Hour 	O Instructor PE Teacher Instructor No.	New Instructor Delete
	Orade Grade	New Grade Delete
	Class Class Name Description	New Class Delete
	Students First Name Last Name Pedometer No Gender Student No	New Student
		Delete

Step 4: Gopher FITstep[™] Pro Pedometer Setup

Setting up a pedometer is a simple process, requiring the embedding of a number to identify the pedometer.

IMPORTANT: The reader station must be connected and set up properly to continue with the pedometer set up. The pedometer may be in deep sleep mode to conserve battery life. To wake the device, press and hold the yellow button entitled 'Reset' until the screen wakes up.

Embedding a Number

It is recommended to physically identify pedometers with numbers on both the outside and inside of each pedometer cover. This will make it easier for students to identify the pedometer they are assigned each time they come to class.

IMPORTANT: The pedometer may be in deep sleep mode to conserve battery life. To wake the device, press and hold the yellow button entitled 'Reset' until the screen wakes up.

To embed a number in the pedometer software, follow these steps:

- 1. In the FITstep[™] application, select the tab entitled "Pedometer Setup" from the tab bar at the top of the app.
- 2. On the Pedometer Setup screen, locate the 'Assign New Pedometer Number' section and select the check box next to "Write New Number."
- 3. Enter the desired number in the box next to the "Write New Number" label that you would like to embed into the pedometer software.
- 4. On the pedometer you are setting up, open the pedometer and place it in the reader station with the screen side up and visible.
- 5. The FITstep[™] software will connect to the pedometer via the reader station and embed the number entered. A message will prompt you when the number has been successfully embedded in the pedometer.
- 6. Upon a successful numbering, the FITstep[™] software will update the number input to the next sequential integer for your convenience.
- 7. Select the next pedometer you would like to set up and place it into the reader station to embed the next sequential number.
- 8. Repeat this process until you have embedded a number for all pedometers.

Checking a Pedometer's Current Number

To check the current number embedded in a pedometer, follow these steps:

- 1. Ensure the pedometer is on showing the current steps count on the screen. You can change the view being shown by pressing the blue 'Mode' button inside the pedometer to the right of the screen.
- 2. Once you are on the 'Steps' screen, press and hold the red 'Set' button to the right of the screen.
- The screen should update to show you the current number embedded in the pedometer. If you were embedding the number 1, the number will appear on the screen as follows: P – 00001.

NOTE: If the pedometer does not have a number embedded in it, pressing and holding the red 'Set' button will not change/update the view on the screen.



Step 5: Class Setup

The Class Setup tab serves as the control center where you will add new instructors, grades, classes and students.

Manual Entry Class Setup

Teachers, students, and classes can be entered into the FITstep[™] software manually by typing the information into each specific field.

Import Students into Class

The Import/Export menu offers the opportunity to import students into the FITstep[™] software using a spreadsheet.

NOTE: Use Excel 2007 or higher (.xlsx) workbook.

The workbook should be set up as follows:

First Name	Last Name	Gender	Pedometer Number	Student Number

- Data cannot be imported unless a first and last name is provided.
- Pedometer numbers must be integers greater than zero.
- The software will accept gender identifiers of "Male", "M", "Boy", or "B" for males.
- The software will accept gender identifiers of "Female", "F", "Girl", or "G" for females.
- The student number field is available for adding student IDs or other unique identifiers. This field accepts characters and numbers.
- Multiple classes can be stored in the same workbook, but each class must be in a separate worksheet.

<u>Step 6: Uploading Pedometer Data into FITstep™</u>

The FITstep[™] application receives data from pedometers via the reader station. The reader station uploads data in approximately 2 seconds per upload. To support a large set of users, the FITstep[™] application will support multiple reader stations connected at the same time. To support multiple reader stations connected via USB, we recommend using a USB hub. You will see the total number of active reader stations connected to your computer in the lower left-hand corner of the application.

IMPORTANT: To upload data from a pedometer, you must have the reader station plugged into your computer via a USB port and have your Class set up correctly in the application. You will know the reader station is connected when an indicator, located under the FITstep[™] logo in the lower left-hand corner of the application, labeled 'FITstepPro Readers: 0' has been updated to now indicate, 'FITstepPro Readers: X', where X is the total number of readers connected.

To upload data from a pedometer to the FITstep[™] software, follow these steps:

1. In the left panel, locate and select the Class for which you want to upload pedometer data.

NOTE: Data cannot be transferred from class to class.

- 2. After selecting a Class, next select the tab entitled 'Upload Pedometer Data' from the tab bar at the top of the app.
- 3. Students should now open the front cover of the FITstep[™] Pro pedometer and place it into the reader station with the screen side facing up and visible.
- 4. As data uploads, the red and green lights on the reader station will flash indicating an upload is in progress. When uploading is complete, only the red light on the reader station will remain on with no flashing.
- 5. During data upload, you can observe the status of each student's pedometer as you watch their names in the left panel. Student names will re-sort automatically and will change colors to indicate the status of the pedometer upload. The following indicates the associated color and status:

BLACK/GRAY: Pedometer is not connected to the reader station

Ensure students pressed the blue button on the outside front cover of the pedometer and released it.

BLUE: Data upload in progress

RED: Data upload failed

This may occur if the pedometer loses connection to the reader station during data upload.

GREEN: Data upload successful

IMPORTANT: The critical part of the upload process is to leave the pedometer in the reader station until the red and green lights on the reader stop flashing.



Any student that is present with their name remaining black/gray or red needs to remove the pedometer and attempt to upload data again using the reader station. Make sure you have accommodated all students present before having them clear step data from their pedometers.

Clearing Pedometer Step Data

Pedometers DO NOT automatically clear data once uploaded to prevent any loss of data should an error occur during the upload. As a result, it is recommended to have students clear the pedometers at the beginning of every class.

IMPORTANT: Ensure that each student clears their pedometer prior to beginning the class activity.

To clear the data on a pedometer, follow these simple steps:

- 1. Open the cover and locate the yellow button labeled 'Reset' to the right of the screen.
- 2. Press and hold the yellow 'Reset' button.
- 3. The screen will flash a few times, and the number of steps taken should reset to zero.

To set up the pedometers to automatically clear after data offload, go to the Options Menu and Select "Clear Pedometer Data After Readings."

NOTE: If the pedometer is cleared and the data transfer fails, there is no way to restore the data.

Monitoring Data Upload in FITstep™

To ensure the FITstep[™] application received data from all students during the upload process, you can reference the total number of workouts that were recorded in the application by monitoring the status bar located at the bottom of the window, next to the reader connection indicator.



A label entitled "Workouts Recorded," along with the current number of recorded workouts and the current number of students in the class that are attempting to transfer their workout data, will appear in the bottom corner.

NOTE: After the uploading process is complete, if you select another class in the left panel and the current class upload process resulted in unsuccessful data transfer, an alert will be presented indicating the unsuccessful uploads.

REPORTS

The Reports Tab is the data analysis center. Click on the Reports Tab to see different types of reports. All reports can be customized to your preferences by sorting, filtering, and dragging and dropping.

- Sorting: The default order of sort is by name in ascending order. To sort any column in descending order, click on the title of the column you want to sort and the order will be reversed. Click it again and it will return to ascending order. Sorting will move entire rows, not just the column you clicked on.
- Date Range: You may choose the date range for all reports. Click on the Date Range indicator in the top right corner of the Reports tab. The date may be entered manually, or by selecting the calendar button.

NOTE: It is not possible to select dates for the Class Roster Report.

• Columns: Select the columns you wish to show in your reports.



Report Details

Students can upload their data multiple times during the day. When the program calculates daily average for each student, it will add together all uploads accumulated in a single day.

- Workouts: Shows all uploads for each student. Every time a student uploads data, it is stored as a workout.
- Weekly Summary: Shows each student and their workouts by week. This allows you to analyze students and your lessons on a week-by-week basis.
- Monthly Summary: Shows each student and their monthly totals and averages.
- Class Roster: Shows the full list of students by class. You can print several classes per print job by command-clicking on selected classes.
- Physical Activity: Allows you to print a "My Physical Activity Report" for each student. The report contains a message to parents and students along with the selected activity sheet (see below).
 - Customize Activity Report command allows for customization of the physical activity report to suit your preferences. Options that can be changed are:
 - Edit Report Title
 - Edit Intro Paragraph
 - Change the School Logo
 - Add Logo to Report

Print function is listed under the File menu. It is available when students have been selected, and the data is listed on the screen.

Report Viewer allows the report to be saved in different formats, including PDF or Word document.

Export to Excel is an option under the file menu. This allows any report chosen to be exported into an Excel spreadsheet.

Preferences Menu

The Preferences Menu allows the user to set some defaults for the software.

Select Start Date. This option is used for selecting a starting date for creating reports and screen analysis of data. This command dictates what the starting date will be when the software is launched. It will always start at one of the options listed below until the setting is changed. The following date range options may be selected:

- Today: Defaults to today.
- Yesterday: Defaults to yesterday.
- Current Week: Defaults to Sunday of the current week.
- Current Month: Defaults to the first day of the current month.
- Current Year: Defaults to January 1 of the current year.
- Last week: Defaults to Sunday of the previous week.
- Last Month: Defaults to the first day of the previous month.
- Fixed Start Date: Defaults to a fixed date that is selected.
- Custom Start Date: Allows data to be viewed from a certain number of days, weeks, months, or years.
 - Select the time period (days, weeks, months, years) to go back, and then select the number of time periods you wish to go back. When using this option, you will not necessarily go back to the start of the week, month, or year. When going back by weeks, it will default to the same day of the week as today. When going back months, it will default to the same day of the month as today. Finally, when going back years, it will default to the same day of the current month in the previous year.

Show Advanced Data Options. This option can be used to check the amount of time students spent in each of the steps per minute levels. The FITstep[™] Pro Pedometers show how much time was spend at each SPM levels (80 to 160) steps per minute). By selecting the advanced data option, this data can be reviewed.

NOTE: This feature only works when viewing the Workouts tab in Reports.

Customize Activity Reports. This option works on the Physical Activity report and can be used to customize reports. It allows changes to be made to the Physical Activity report to suit the school preferences. The changes can be reviewed using the preview selection.



The options that can be changed are:

- Edit Report Title
- Edit Intro Paragraph
- Change the School Logo
- Add Logo to Report

Help Menu

The Help Menu provides easy access to the FITstep[™] Software Instructions for reference during use. Additional information can be found by following the Gopher Sport Web Links.

Future updates to the FITstep[™] Software will be available for download at <u>www.gophersport.com/software</u>